



[rebeltec]

2in1 Universal Tablet car mount

User Manual:

Mounting tablet to the holder

1. To install the device in the holder tablet press lock button (behind the holder).
2. Insert the device in the correct position and tighten the arm.
3. To remove the device from the holder , gently squeeze the arms and release the lock button opening.

Mounting suction cup to the windshield

1. Thoroughly clean the glass, which will be installed on the suction cup .
2. Remove the protective film from the silicone suction cup and then place it face down , and then slide lock toward the windshield . Make sure the suction cup is attached firmly .

Mounting bracket for headrest

1. Attach the bracket to grab headrest in your car with the special bolts. Make sure the bracket is mounted securely .

Attaching the tablet in the suction cup / bracket head restraint

1. Connect the tablet holder with suction cup / headrest bracket by pressing one element to another and shifting element down until it clicks . Make sure that the handle is attached firmly
-

Instrukcja obsługi:

Montaż tabletu w uchwycie

1. Aby zamontować urządzenie w uchwycie tabletu wciśnij przycisk rozszerzający ramiona.
2. Wstaw urządzenie w odpowiedniej pozycji i zaciśnij od tyłu ramiona.
3. Aby wyjąć urządzenie z uchwytu , delikatnie ściśnij ramiona i zwolnij ich blokadę przyciskiem rozszerzającym.

Montaż przyssawki na szybie

1. Dokładnie oczyść z zabrudzeń miejsce na szybie, w którym będzie instalowana przyssawka.
2. Zdejmij ochronną folię z silikonowej przyssawki a następnie przyłóż ją do szyby i przesunź zatrask w kierunku szyby. Upewnij się że przyssawka jest zamocowana solidnie.

Montaż chwytaka na zagłówku fotela

1. Przymocuj chwytak zagłówekowy do pałaków zagłówka w twoim samochodzie za pomocą śrub ręcznych. Upewnij się chwytak jest zamocowany solidnie.

Montaż uchwytu tabletu w przyssawce/chwytaku zagłówka

1. Połącz uchwyt tabletu z przyssawką/chwytakiem zagłówka poprzez wciśnięcie jednego elementu w drugi oraz przesunięcie elementu w dół aż do charakterystycznego kliknięcia. Upewnij się że uchwyt jest zamocowany solidnie.